

# INDEX - VICs (VEHICLE INSTRUCTION CARD)

## SMART VEHICLES

| Page | Vehicle   | Details                    |
|------|---|----------------------------|
| 1    | <b>Index</b>                                      | n/a                        |
| 2    | <b>Supplement (Electronic Parking Brake, etc)</b> | n/a                        |
| 3    | <b>Forfour</b>                                    | 5 seats / 5 door hatchback |
| 4    |   |                            |
| 5    |   |                            |
| 6    |   |                            |
| 7    |   |                            |
| 8    |   |                            |
| 9    |   |                            |
| 10   |   |                            |
| 11   |   |                            |
| 12   |   |                            |
| 13   |   |                            |
| 14   |   |                            |
| 15   |   |                            |
| 16   |   |                            |
| 17   |   |                            |
| 18   |   |                            |
| 19   |   |                            |
| 20   |   |                            |

# VEHICLE INSTRUCTION CARD SUPPLEMENT

No responsibility is accepted for inaccuracies or misunderstanding caused by the wording of this guide. If in any doubt ask a member of staff for assistance.

## DEADLOCKS

Deadlock / safelock messages shown on the instrument display when the engine is turned off simply indicate that once you exit the vehicle and lock the doors, they're effectively deadlocked and anyone left in the car wouldn't be able to get out in the event of an emergency. The warning is nothing to worry about and is just a standard advisory message.

## SEATBELT WARNING LIGHTS

A seatbelt warning light may illuminate when the engine is turned on. To deactivate these warning lights, and turn off the auto activation, ensure all passengers fasten their seatbelts, and remove any luggage from on top of the seats. For safety secure all luggage inside the boot.

## WARNING LIGHTS AND WHAT THEY MEAN

Don't panic! Despite seeing a new light pop-up on your instrument panel, unless it is red it is likely the car is still running fine, and while there may be a problem to attend to, proceed with confidence and patience.

### **RED**

Red indicates a potentially serious problem or safety issue. Attend to it! Red may also indicate an important reminder.

### **YELLOW**

Yellow/orange means something needs to be serviced or repaired soon. If it is flashing, it is important that you contact your rental agent for advice.

### **GREEN**

Green or blue is only telling you that a system is on or operating normally.

# VEHICLE INSTRUCTION CARD

**For assistance after an accident/incident, please call 0800 0280 999**  
 For assistance after a breakdown or help with tyres or windscreens please refer to the numbers on the tax disc holder.

## CONTROLS

- 1 Heating & Ventilation
- 2 Hazard Lights
- 3 Starter Switch
- 4 Headlights
- 5 Sidelights
- 6 Indicators
- 7 Wipers
- 8 Rear Screen Wipers
- 9 Horn
- 10 Bonnet Release
- 11 Heated Rear Screen
- 12 Rear Fog Lamp
- 13 Front Fog Lamp



### CAUTION!

When parked, the parking brake should be fully applied with the vehicle left in first or reverse gear for vehicles equipped with manual transmission or P (Park) for vehicles with automatic transmission.

## TYRE PRESSURES (COLD)

Check tyre pressure regularly  
 Legal minimum tread depth is 1.6 mm

- 185/60 R15
- 185/65 R15
- 185/50 R16
- 205/45 R16

Check the tyre pressure table found on the inside of driver's door B-pillar (or fuel filler cap).

Some models may be fitted with an electronic tyre pressure monitor.

Note: driving speeds and travel distances are restricted when using the tyre repair kit.

**NOTE: SHOULD THIS VEHICLE NOT BE SUPPLIED WITH A SPARE WHEEL, PLEASE REFER TO THE TELEPHONE NUMBERS SHOWN ON THE TAX DISC HOLDER.**

## FUEL

Ensure you use the correct fuel type. Only use unleaded petrol in petrol vehicles (see inside of filler flap).

Fuel Tank Capacity:  
 35.0 litres

## IN CASE OF BREAKDOWN

Use hazard lights. Attempt to park in a safe position.


Use an emergency phone rather than a mobile as emergency services will then know the location of the vehicle.

## CHILD SEATS

Never use a child seat in a front passenger seat which is fitted with an active airbag (SRS). Follow all fitting instructions carefully.

Check seat positioning and security before use.

## DRIVER'S SEAT



Vehicle specifications are subject to change. When the engine is turned off, ensure that the starter switch is in position II when operating electrical items such as door mirrors and windows, etc. **This vehicle does not include any manufacturer handbooks or manuals.**

## USEFUL INFORMATION ABOUT YOUR VEHICLE

- Locking the doors?** Key / remote control operated central locking. Depress the central locking button on the centre console to lock the doors from the inside, or depress the door locking knobs. Doors auto-lock as vehicle is driven.
- Anti-theft system?** Most vehicles are fitted with an alarm system. Passive arming of electronic engine immobiliser after removal of the key from the starter switch.
- Opening boot/tailgate?** Centrally locked. Use the key or remote control to unlock / open.
- Adjusting door mirrors?** Electric internal adjustment operated via a control knob on the driver's door.
- Opening the windows?** Electric front and rear operated via control switches on the driver's door.
- Operating the sunroof?** If fitted: electric panoramic sunroof operated by roof mounted switchgear.
- Using child door locks?** Fitted to the rear passenger doors. To operate press the central locking switch on the driver's door. Ensure the doors are securely locked. Doors auto-lock as vehicle is driven.
- Starting the engine?** Ensure gear selector is in neutral (or N or P if automatic) and handbrake is on. Place ignition key in starter switch. Use a normal starting routine. Select desired gear. Release handbrake and brake pedal and gently press the accelerator to move the vehicle. Some models feature auto engine start/stop technology whereby the engine switches off when the vehicle is motionless, neutral gear is selected, and foot pedals are not depressed - press the clutch (or accelerator if auto) to instantly restart the engine.
- Opening fuel filler cap?** Centrally locked. Located under flap on rear offside. Lift the edge of the flap to open it, and twist the cap off anticlockwise.
- Releasing the bonnet?** Pull the bonnet release lever located on the right side panel in the driver's foot well. Pull the release lever which protrudes through the bonnet grille to release the bonnet.
- Folding the rear seats?** The rear seat is divided into sections which can be flat-folded separately. To release the seat press the seat unlocking catch and fold the seat down. To return the seat to normal use, raise the seat and push it firmly to engage the seat lock. Check it is locked before using the seat.
- How to change a tyre?** The tyre repair kit, tools and jack are stored in the side storage bins. Move the vehicle to firm / level ground. Turn the engine off, select first gear (manual) or P (automatic). Apply the handbrake. Follow the tyre repair kit instructions. [Only if necessary: loosen the wheel nuts by turning them anticlockwise (do not remove them) before jacking up. Only use the specific reinforced jack points on the underside of the vehicle. Crank the jack to lift the vehicle. Completely loosen / remove nuts and wheel and replace the wheel. Refit / tighten the wheel nuts. Lower the vehicle. Tighten the wheel nuts.]
- How to drive an automatic?** To change gears press the button on the shift lever and move the lever forwards or backwards. Select N for neutral, P when leaving the vehicle, R for reversing (the vehicle must be at a complete standstill before this gear can be selected). For normal driving select D where the transmission will use all available forward gears automatically (a 'kickdown' facility is provided when the accelerator is pressed all the way to the floor past the normal acceleration point forcing the transmission to select a lower gear to obtain maximum acceleration. Release pressure on the accelerator to return to normal accelerator use). Use + or - to manually change gears up or down. Whenever the vehicle is at a standstill apply the electronic parking brake.

No responsibility is accepted for inaccuracies or misunderstanding caused by the wording of this guide. If in any doubt ask a member of staff for assistance.

VIC-SMT-01 / 10-01-2016

# SMART FORFOUR

**5 SEATS  
 5 DOOR HATCHBACK**